

**3.1.1.3 T1067**

**CMG-1T CALIBRATION SHEET**

WORKS ORDER: 4146                      DATE: 12-Aug-2009  
 SERIAL NUMBER: T1067                  TESTED BY: S. Goddard

	Velocity Output V/m/s (Differential)	Mass Position Output (Acceleration output) V/m/s <sup>2</sup>	Feedback Coil Constant Amp/m/s <sup>2</sup>
VERTICAL	2 x 742	2149	0.01423
NORTH/SOUTH	2 x 747	1435	0.01435
EAST/WEST	2 x 741	1436	0.01436

Power Consumption: 60mA @ +12V input  
 Calibration Resistor: 51000

NOTE: A factor of 2 x must be used when the sensor outputs are used differentially (also known as push-pull or balanced output). Under no conditions should the negative outputs be connected to the signal ground. A separate signal ground pin is provided.

---

**POLES AND ZEROS TABLE**
**WORKS ORDER NUMBER: 4146****SENSOR SERIAL NO: T1067**

Velocity response output, Vertical Sensor:

<u>POLES (HZ)</u>	<u>ZEROS (HZ)</u>
$-1.964 \times 10^{-3} \pm j1.964 \times 10^{-3}$	0
-30.0529±j31.1211	0
-41.2564±j114.535	

Normalizing factor at 1 Hz: A =  $27.7 \times 10^6$ 

Sensor Sensitivity: See Calibration Sheet.

Velocity response output, Horizontal Sensors:

<u>POLES (HZ)</u>	<u>ZEROS (HZ)</u>
$-1.964 \times 10^{-3} \pm j1.964 \times 10^{-3}$	0
-30.0529±j31.1211	0
-41.2564±j114.535	

Normalizing factor at 1 Hz: A =  $27.7 \times 10^6$ 

Sensor Sensitivity: See Calibration Sheet.

**NOTE:** The above poles and zeros apply to the vertical and the horizontal sensors and are given in units of Hz. To convert to Radian/sec multiply each pole or zero with  $2\pi$ . The normalizing factor A should also be recalculated.